

Build Your Own Data Logger

Module 4: Tying it All Together

Terminology Starter Guide

Video	
Block Diagram	A high level diagram which shows the relationship between the key functionality or components of a device.
NaN (Not a Number)	A data type that indicates the system is receiving an undefined or unrepresentable value. In this case, it indicates the WildLogger system isn't receiving floating point numbers from the sensor.